



Heating and Air Conditioning

**INSTALLATION MANUAL**  
**AFFINITY OUTDOOR SPLIT**  
**GEOTHERMAL HEAT PUMPS**  
**DUAL CAPACITY**

**MODELS:**

**YAST026 - 072**

**(2 THRU 6 NOMINAL TONS)**



Due to continuous product improvement, specifications are subject to change without notice.

Visit us on the web at [www.york-geothermal.com](http://www.york-geothermal.com)

Additional rating information can found at  
[www.ahrirectory.org](http://www.ahrirectory.org)

FOR DISTRIBUTION USE ONLY - NOT TO BE USED AT POINT OF RETAIL SALE




## Table of Contents

---

Model Nomenclature . . . . .	4
General Installation Information . . . . .	5-7
Water Quality . . . . .	8
Water Piping . . . . .	9
Electrical Connections . . . . .	10
Electronic Thermostat Installation . . . . .	11-12
Electrical Data . . . . .	13
Dimensional Data . . . . .	14
Physical Data . . . . .	14
Air Handler Data . . . . .	15
“A” Coil Data . . . . .	16
The Aurora™ Control System . . . . .	17-22
Reference Calculations . . . . .	23
Legend . . . . .	23
Operating Limits . . . . .	23
Wiring Schematics . . . . .	24-27
Refrigeration . . . . .	28-29
Line Set Sizes . . . . .	29
Pressure/Temperature Conversion Chart for R-410A . . . . .	30
Unit Startup . . . . .	31-33
Operating Parameters . . . . .	34
Pressure Drop . . . . .	35
Compressor and Thermistor Resistance . . . . .	35
Refrigerant Circuit Guideline . . . . .	36
Heat of Extraction/Rejection Data . . . . .	36
Troubleshooting . . . . .	37-39
Preventative Maintenance . . . . .	40
Replacement Procedures . . . . .	40
Service Parts List . . . . .	41
Revision Guide . . . . .	42

## Model Nomenclature



## General Installation Information

### Safety Considerations



**WARNING:** Before performing service or maintenance operations on a system, turn off main power switches to both units. Turn off accessory heater power switch if applicable. Electrical shock could cause personal injury. Installing and servicing heating and air conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair or service heating and air conditioning equipment.

Installing and servicing heating and air conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair or service heating and air conditioning equipment. Untrained personnel can perform the basic maintenance functions of cleaning coils and cleaning and replacing filters. All other operations should be performed by trained service personnel. When working on heating and air conditioning equipment, observe precautions in the literature, tags and labels attached to the unit and other safety precautions that may apply, such as the following safety measures:

- Follow all safety codes.
- Wear safety glasses and work gloves.
- Use a quenching cloth for brazing operations.
- Have a fire extinguisher available for all brazing operations.

### Moving and Storage

Move units in the normal "up" orientation. Units may be moved and stored per the information on the packaging. Do not stack more than three units in total height. Do not attempt to move units while stacked. When the equipment is received, all items should be carefully checked against the bill of lading to be sure all crates and cartons have been received. Examine units for shipping damage, removing the units from the packaging if necessary. Units in question should also be internally inspected. If any damage is noted, the carrier should make the proper notation on the delivery receipt, acknowledging the damage.

### Split Unit Location

Locate the split compressor section away from areas that may disturb the customer and in a way that allows easy removal of the access panels and the top of the cabinet. Provide sufficient room to make water, electrical and refrigerant line connections and allow space for service personnel to perform maintenance. The NDS split is approved for outdoor installation when properly installed.

### Air Coil Location

Refer to the air handler manufacturer's instructions for the blower coil unit for details on installing the air handling portion of the system.

### Condensate Drain

Follow the blower coil manufacturer's instructions.

### Duct System

All blower coil units/air coils must be installed as specified by the manufacturer's installation instructions; however, the following recommendations should be considered to minimize noise and service problems.

An air filter must always be installed upstream of the air coil on the return air side of the air handler or furnace. If there is limited access to the filter rack for normal maintenance, it is suggested that a return air filter grill be installed. Be sure that the return duct is properly installed and free of leaks to prevent dirt and debris from bypassing the filter and plugging the air coil.

In applications using galvanized metal ductwork, a flexible duct connector is recommended on both the supply and return air plenums to minimize vibration from the blower. To maximize sound attenuation of the unit blower, the supply and return plenums should include an internal duct liner of 1-inch thick glass fiber or be constructed of ductboard. Insulation is usually not installed in the supply branch ducts. Ducts in unconditioned areas should be wrapped with a minimum of 1-inch duct insulation. Application of the unit to uninsulated ductwork in an unconditioned space is not recommended as the unit's performance will be adversely affected. If the air handler is connected to existing ductwork, a previous check should have been made to assure that the duct system has the capacity to handle the air required for the unit application. If ducting is too small, as in replacement of heating only systems, larger ductwork should be installed. All existing ductwork should be checked for leaks and repairs made accordingly. The duct systems and diffusers should be sized to handle the design airflow quietly. If air noise or excessive airflow is a problem, the blower speed can be changed to a lower speed to reduce airflow. This will reduce the performance of the unit slightly in heating; however, it will increase the temperature rise across the air coil. Airflow must still meet minimum requirements.

### Equipment Selection

The following guidelines should be used when mating a Outdoor Split to an air handler/coil.

- Select R-410A components only.
- Match the air handler to the air handler coil data table.
- Indoor matching adjustable TXV is factory installed on every air handler/coil. Fixed orifice or cap tube systems should not be used.
- Minimum of two (2) blower speeds

### Utilizing Existing Coil or Air Handler

It is recommended that a new R-410A air handler be installed with a Outdoor Split considering the long term benefits of reliability, warranty, etc. versus the short term installation cost savings. However, the existing air handler may be retained provided the following:

- Coil currently is R-410A rated
- Coil uses a TXV. No capillary or fixed orifice systems should be used
- A life expectancy of more than 7 years remaining for the air handler and components
- Flush air coil and line set

## General Installation Information cont.

When utilizing the existing air coil or line set, only flushing compounds that vaporize should be used; which means they are packaged in a pressurized disposable cylinder. It is preferable to use a flushing agent that removes oil, water, and acid, plus, is biodegradable and non-toxic. The flushing agent should be safe to use with both HCFC and HFC refrigerants. Once a flushing agent has been selected, follow the instructions provided with the product.

The first step should be purging the lines or air coil with nitrogen. Purging with nitrogen first will remove some of the particulate and residual oil which will allow the flushing agent to work better. Never blow the flushing agent through a compressor, filter drier, or txv as it will cause the components to fail.

When flushing is complete and the final system is assembled, an acid check should be performed on the system. Acid test kits are available from most HVACR distributors.

### Connection to Air Coil

Typical Split System Application - Remote Blower Coil and Typical Split System Heat Pump Coil Add-on Fossil Fuel Furnace illustrations show typical Outdoor Split installations. The Line Set Sizes table shows typical line set diameters and maximum length. Line sets over 60 feet are not recommended. If the line set is kinked or deformed and cannot be reformed, the bad section of pipe should be replaced. A restricted line set will affect unit performance. As in all R-410A equipment, a reversible liquid line filter drier is required to ensure all moisture is removed from the system. This drier should be replaced whenever "breaking into" the system for service. All line sets should be insulated with a minimum of 1/2" closed cell insulation. All exterior insulation should be painted with UV resistant paint or covering to ensure long insulation life.

### Air Handler Installation

Air handlers used with dual capacity units must be capable of operating with a minimum of 2 blower speeds. Refer to the manufacturer's instructions for the blower coil unit for details on installing the air handling portion of the system. All blower coil units/air coils must be installed as specified by the manufacturer's installations instructions. However, the following recommendations should be considered to minimize noise and service problems.


An air filter must always be installed upstream of the air coil on the return air side of the air handler or furnace. If there is limited access to the filter rack for normal maintenance, it is suggested that a return air filter grille be installed. Be sure that the return duct is properly installed and free of leaks to prevent dirt and debris from bypassing the filter and plugging the air coil.

Ensure that the line set size is appropriate to the capacity of the unit (refer to Line Set Sizes table). Line sets should be routed as directly as possible, avoiding unnecessary bends or turns. All wall penetrations should be sealed properly. Line set should not come into direct contact with water pipes, floor joists, wall studs, duct work, floors, walls and brick. Line set should not be suspended from joists or studs with a rigid wire or strap which comes into

direct contact with the tubing. Wide hanger strips which conform to the shape of the tubing are recommended. Isolate hanger straps from line set insulation by using metal sleeves bent to conform to the shape of insulation. Line set insulation should be pliable, and should completely surround the refrigerant line.

**NOTE:** Improper installation of equipment may result in undesirable noise levels in the living areas.

### Typical Split System Application - Remote Blower Coil



## General Installation Information cont.


### Dual Fuel Systems

Outdoor split units can be connected to fossil fuel furnaces that include an A-coil or slab coil. Dual fuel installations utilize the outdoor split heat pump for heating until the point that auxiliary heat is called for on the thermostat. At that point, the furnace will be enabled and the heat pump will be disabled. The outdoor split heat pump provides air conditioning through the furnace's refrigerant coils.

Refer to the furnace manufacturer's installation manual for the furnace installation, wiring and coil insertion. A Dual Fuel thermostat or a field-installed SPST relay is required. See the Typical Split System Heat Pump Coil Add-on Fossil Fuel Furnace illustration for typical Dual Fuel application.

In add-on Outdoor Split applications, the coil should be located in the supply side of the furnace to avoid condensation damage to the furnace heat exchanger. A high temperature limit should be installed upstream of the coil to de-energize the compressor whenever the furnace is operating. Without this switch, the Outdoor Split will trip out on high pressure. A dual fuel thermostat can remove the Y1 and Y2 calls when a W call is energized to allow gas furnace backup on a Outdoor Split application. Refer to the Thermostat Wiring section for details.

### Typical Split System Heat Pump Coil Add-on Fossil Fuel Furnace



## Water Quality

In ground water situations where scaling could be heavy or where biological growth such as iron bacteria will be present, a closed loop system is recommended. The heat exchanger coils in ground water systems may, over a period of time, lose heat exchange capabilities due to a buildup of mineral deposits inside. These can be cleaned, but only by a qualified service mechanic, as special solutions and pumping equipment are required. Hot water generator coils can likewise become scaled and possibly plugged. In areas with extremely hard water, the owner should be informed

that the heat exchanger may require occasional flushing. Failure to adhere to the guidelines in the water quality table could result in loss of warranty.

Units with cupronickel heat exchangers are recommended for open loop applications due to the increased resistance to build-up and corrosion, along with reduced wear caused by acid cleaning.

Material		Copper	90/10 Cupronickel	316 Stainless Steel
pH	Acidity/Alkalinity	7 - 9	7 - 9	7 - 9
Scaling	Calcium and Magnesium Carbonate	(Total Hardness) less than 350 ppm	(Total Hardness) less than 350 ppm	(Total Hardness) less than 350 ppm
Corrosion	Hydrogen Sulfide	Less than 0.5 ppm (rotten egg smell appears at 0.5 ppm)	10 - 50 ppm	Less than 1 ppm
	Sulfates	Less than 125 ppm	Less than 125 ppm	Less than 200 ppm
	Chlorine	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Chlorides	Less than 20 ppm	Less than 125 ppm	Less than 300 ppm
	Carbon Dioxide	Less than 50 ppm	10 - 50 ppm	10 - 50 ppm
	Ammonia	Less than 2 ppm	Less than 2 ppm	Less than 20 ppm
	Ammonia Chloride	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Ammonia Nitrate	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Ammonia Hydroxide	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Ammonia Sulfate	Less than 0.5 ppm	Less than 0.5 ppm	Less than 0.5 ppm
	Total Dissolved Solids (TDS)	Less than 1000 ppm	1000 - 1500 ppm	1000 - 1500 ppm
	LSI Index	+0.5 to -0.5	+0.5 to -0.5	+0.5 to -0.5
Iron Fouling (Biological Growth)	Iron, $FE^{2+}$ (Ferrous) Bacterial Iron Potential	< 0.2 ppm	< 0.2 ppm	< 0.2 ppm
	Iron Oxide	Less than 1 ppm, above this level deposition will occur	Less than 1 ppm, above this level deposition will occur	Less than 1 ppm, above this level deposition will occur
Erosion	Suspended Solids	Less than 10 ppm and filtered for max. of 600 micron size	Less than 10 ppm and filtered for max. of 600 micron size	Less than 10 ppm and filtered for max. of 600 micron size
	Threshold Velocity (Fresh Water)	< 6 ft/sec	< 6 ft/sec	< 6 ft/sec

**NOTES:** Grains = ppm divided by 17  
mg/L is equivalent to ppm

2/22/12



## Water Piping

Residential split units are supplied standard with GeoLink swivel connections with P.T. ports.



**CAUTION:** Water piping exposed to outside temperatures may be subject to freezing.

### Water Piping

The proper water flow must be provided to each unit whenever the unit operates. To assure proper flow, use pressure/temperature ports to determine the flow rate. These ports should be located at the supply and return water connections on the unit. The proper flow rate cannot be accurately set without measuring the water pressure drop through the refrigerant-to-water heat exchanger.

### Closed Loop - Earth coupled Systems (Outdoor Installations)

Locate unit on an air pad with access hole as shown below. When mounting on an existing concrete pad, holes must be bored through to accommodate 1 1/4-inch P.E. pipe with 1/2-inch insulation.

### Connecting To Earth Loop

The earth loop trench should be continued directly under the unit as shown in the Typical Split System Outdoor Installation Using Closed Loop. Make the connections to optional fittings from the loop circulator pump(s) and ensure proper backfill to support the loop pipe during trench settling. All 1 1/4-inch piping should be insulated with a minimum of 1/2-inch closed cell insulation from below the ground surface to the loop circulator.



**IMPORTANT:** A freeze detection thermostat is installed in the unit to automatically start loop circulator pump if loop temperature drops below 20°F. Loop freeze detection should also be maintained to the lowest temperature the insulated loop may encounter in the case of power failure.

### Open Loop (Indoor Installations)


Outdoor Splits can be installed on an open loop system, but only indoors. All Outdoor Splits are supplied with GeoLink swivel connectors. The swivel connectors will also accept a 1 in. O.D. copper pipe (sweat) which can be connected in an open loop system.

### Flow Center Installation

Flow centers FC1-GL or FC2-GL, as needed, may be internally mounted on the outdoor split. Two stub tubes with barbs are pre connected to the coax. Two tubes with brass fittings, to adapt to the flow center, 2 hoses to connect between the two sets of tubes, and four hose clamps are included with each outdoor split unit. The brass adapter fittings have plastic swivel connectors that also accept 1 in. O.D. copper pipe (sweat).

**NOTE:** For ease of installation, attach provided hoses to coax first and then trim to fit to elbows on flow center.

### Typical Split System Outdoor Installation Using Closed Loop



## Electrical Connections

### General

Be sure the available power is the same voltage and phase as that shown on the unit serial plate. Line and low voltage wiring must be done in accordance with local codes or the National Electric Code, whichever is applicable.

### Unit Power Connection

Connect the incoming line voltage wires to L1 and L2 of the contactor as shown in Figure 13C for single-phase unit. Consult the Unit Electrical Data in this manual for correct fuse sizes.

Open front access panel. Insert power wires through knockouts on the bottom side of cabinet (Figure 13A). Route wires through the bottom of the control box and connect to contactor and ground (Figure 13B). Close control box and replace fastener before unit start-up.

### Accessory Relay

A set of “dry” contacts has been provided to control accessory devices, such as water solenoid valves on open loop installations, electronic air cleaners, humidifiers, etc. This relay contact should be used only with 24 volt signals and not line voltage power. The relay has both normally open and normally closed contacts and can operate with either the fan or the compressor. Use DIP switch SW2-4 and 5 to cycle the relay with blower, compressor, or control a slow opening water valve. The relay contacts are available on terminals #2 and #3 of P2.

When powering high VA draw components such as electronic air cleaners or VM type open loop water valves, R should be taken ‘pre-fuse’ from the ‘R’ quick connect on the ABC board and not the ‘post-fuse’ ‘R’ terminal on the thermostat connection. If not, blown ABC fuses might result.


### 208 Volt Operation

All 208/230 units are factory wired for 230 volt operation. For 208 volt operation, the red and blue transformer wires must be switched on terminal strip PB2.

**Figure 13A:**  
Wire access (control box open)



**Figure 13B:**  
Line Voltage 208-230/60/1 control box




## Electrical Connections cont.

### Pump Power Wiring

See Figure 14 for electrical connections from control box to pumps.

FC1/FC2 style flow centers with fixed speed pumps connect to PB1 in the control box.

Figure 14: Pump Wiring 208-230/60/1




## Electronic Thermostat Installation

Position the thermostat subbase against the wall so that it is level and the thermostat wires protrude through the middle of the subbase. Mark the position of the subbase mounting holes and drill holes with a 3/16-inch bit. Install supplied anchors and secure base to the wall. Thermostat wire must be 8-conductor (4 or 5 conductor for communicating thermostats), 20-AWG (minimum) wire. Strip the wires back 1/4-inch (longer strip lengths may cause shorts) and insert the thermostat wires into the connector as shown. Tighten the screws to ensure secure connections. The thermostat has the same type connectors, requiring the same wiring. See instructions enclosed in the thermostat for detailed installation and operation information.


**NOTE:** Aurora Base Control (ABC) DIP switch SW2-7 is required to be in the "OFF" position for the control to operate with FaultFlash or ComforTalk thermostats. SW2-7 in the "ON" position configures the control to operate with typical thermostats (continuous lockout signal). There must be a wire connecting Y2 on the Aurora controller to 2nd stage compressor on the thermostat for proper operation.

Figure 15: Thermostat Wiring (Y1 Style Signals)




# Electronic Thermostat Installation cont.

## Thermostat Wiring



Air Handler transformer must be at least 75 VA.

## Thermostat Wiring for Dual Fuel Applications



## Electrical Data


Model	Rated Voltage	Voltage Min/Max	Compressor				Ext Loop FLA	Total Unit FLA	Min Circ Amp	Max Fuse/HACR
			MCC	RLA	LRA	LRA*				
<b>026</b>	208-230/60/1	187/253	18.2	11.6	58.3	21.0	5.4	17.0	19.9	30
<b>038</b>	208-230/60/1	187/253	23.8	15.2	83.0	30.0	5.4	20.6	24.4	40
<b>049</b>	208-230/60/1	187/253	33.0	21.1	104.0	37.0	5.4	26.5	31.8	50
<b>064</b>	208-230/60/1	187/253	42.3	27.1	152.9	54.0	5.4	32.5	39.3	70
<b>072</b>	208-230/60/1	187/253	46.3	29.6	179.2	63.0	5.4	35.0	42.4	75

Rated voltage of 208-230/60/1.  
HACR circuit breaker in USA only.  
Min/Max voltage of 187/253.  
All fuses Class RK-5  
\* With optional GeoStart

7/10/13

## Dimensional Data

### Cabinet Dimensions and Refrigerant Piping Connections



Model		A	B	C	D	E	F	G	H	I	J	K	L	M
026 thru 072	in	36.0	23.9	26.7	9.3	7.1	9.0	5.6	8.2	10.7	18.9	8.7	14.8	7.0
	[cm]	[91.4]	[60.7]	[67.8]	[23.7]	[18.0]	[22.8]	[14.2]	[20.9]	[27.2]	[48.0]	[22.1]	[37.6]	[17.8]

Refer to Physical Dimensions and Piping Connections drawings


## Physical Data

Model	026	038	049	064	072
Compressor (1 each)	Dual Capacity Scroll				
Factory Charge R-410A, oz [kg]	52 [1.47]	56 [1.59]	90 [2.55]	92 [2.61]	104 [2.95]
Coax and Water Piping	GeoLink Swivel Connectors				
Water Connections Size - Swivel- in [mm]	3/8 [9.525]				
Brass Service Valve - Liquid Line - in [mm]	3/8 [9.525]				
Brass Service Valve - Suction Line - in [mm]	5/8 [15.875]	3/4 [19.05]		7/8 [22.225]	
Coax and Piping Water Volume - gal [l]	0.7 [2.6]	1.3 [4.9]	1.6 [6.1]	1.6 [6.1]	1.6 [6.1]
Weight - Operating, lb [kg]	189 [86]	236 [107]	250 [113]	271 [123]	290 [132]
Weight - Packaged, lb [kg]	209 [95]	256 [116]	270 [122]	291 [132]	310 [141]

All units have TXV expansion devices, and 1/2 in. [12.2 mm] and 3/4 in. [19.1 mm] electrical knockouts.  
Brass service valves are sweat type valves.

5/24/13

## Model Nomenclature - Air Handler



Rev.: 16 August 2013D

**NOTE:** To field convert the YAH042-060 to bottomflow air discharge, the NAHBC kit must be ordered.

## Coil Data - Air Handler

Outdoor Split Model	Matching Air Handler	Coil Surface Area (ft²)	FPI	Rows	Tube Diameter
022 - 038	YAH036	5.83	12	2	3/8 in.
042 - 072	YAH060	5.83	12	3	3/8 in.

## Compatibilty Table - Air Handler

### Air Handler Sizing Selection


The Affinity Air Handlers are designed for R-410A refrigerant and should be matched with Affinity Split compressor section according to the table below.

Air Handler	Indoor Split Model (Single)	Indoor Split Model (Dual Capacity)	Outdoor Split Model (Dual Capacity)	Airflow (CFM)	Electric Heat (kW)
YAH022A***1R	YAZS022	-	-	800	5
YAH026A***1R	-	YAZT026	YAST026	925	5
YAH030A***1R	YAZS030	-	-	980	5, 10
YAH036A***1R	YAZS036	-	-	1225	5, 10
YAH036A***1R	-	YAZT038	YAST038	1225	5, 10
YAH042A***1R	YAZS042	-	-	1425	10, 15
YAH048A***1R	YAZS048	-	-	1625	10, 15
YAH048A***1R	-	YAZT049	YAST049	1625	10, 15
YAH060A***1R	YAZS060	-	-	1760	10, 15, 20
YAH060A***1R	-	YAZT064	YAST064	1760	10, 15, 20
YAH060A***1R	YAZS070	-	-	1760	10, 15, 20
YAH060A***1R	-	YAZT072	YAST072	1760	10, 15, 20

## Physical Data - Air Handler

Air Handler Model Number (Refrigerant)		YAH022	YAH026	YAH030	YAH036	YAH042	YAH048	YAH060
Evaporator Coil	Air Coil Total Face Area - ft² [m²]	5.83 [0.54]						
	Tube Outside Diameter - in [mm]	3/8 [9.52]						
	Number of Rows	2				3		
	Fins Per Inch	12						
	Suction Line Connection - in [mm] Sweat	5/8 [15.87]				7/8 [22.22]		
	Liquid Line Connection - in [mm] Sweat	3/8 [9.52]						
Refrigerant		R-410a						
Nominal Cooling Capacity - Ton [kW]		1.8 [6.44]	2.1 [7.59]	2.5 [8.79]	3.0 [10.55]	3.5 [12.30]	4.0 [14.06]	5 [17.58]
Condensate Drain Connection - (FPT) in [mm]		3/4 [19.05]						
Blower Wheel Size - (Dia x W) in [mm]		11 x 10 [279 x 254]						
Blower Motor Type/Speeds		Variable Speed ECM						
Blower Motor Output - hp [W]		1/2 [373]				1 [746]		
Filter Standard - 1" [51mm] MERV3 Disposable - in [mm]		20 x 24 [508 x 635]						
Electrical Characteristics (60hz)		208/230/60/1						
Shipping Weight - lbs [kg]		215 [97.52]				220 [99.79]		
Operating Weight - lbs [kg]		195 [88.45]				200 [90.71]		

## Model Nomenclature - Coil



Rev.: 16 August 2013D

## Refrigerant Coil Compatibility

Encased/Uncased Coil	Indoor Split Model (Single)	Indoor Split Model (Dual Capacity)	Outdoor Split Model (Dual Capacity)	Recommended Airflow (CFM)
YRAC026*	YAZS022	-	-	800
YRAC026*	-	YAZT026	YAST026	925
YRAC026*	YAZS030	-	-	980
YRAC036*	YAZS036	-	-	1225
YRAC036*	-	YAZT038	YAST038	1225
YRAC048*	YAZS042	-	-	1425
YRAC048*	YAZS048	-	-	1625
YRAC048*	-	YAZT049	YAST049	1625
YRAC060*	YAZS060	-	-	1760
YRAC060*	-	YAZT064	YAST064	1760
YRAC060*	YAZS070	-	-	1760
YRAC060*	-	YAZT072	YAST072	1760


7/14/08




## The Aurora™ Control System



### Aurora 'Base' Control

The Aurora 'Base' Control (ABC) System is a complete residential and commercial comfort system that brings all aspects of the HVAC system into one cohesive module network. The ABC features microprocessor control and HP, LP, condensate and freeze detection, over/under voltage faults, along with communicating thermostat capability for complete fault detection text at the thermostat.




Aurora uses the Modbus communication protocol to communicate between modules. Each module contains the logic to control all features that are connected to the module. The Aurora 'Base' Control (ABC) has two Modbus channels. The first channel is configured as a master for connecting to devices such as a communicating thermostat, expansion board, or other slave devices. The second channel is configured as a slave for connecting the Aurora Interface Diagnostics Tool (AID Tool).

Service Device	Description	Aurora 'Base'
 <b>Aurora Interface and Diagnostics (AID) Tool</b>	Allows setup, monitoring and troubleshooting of any Aurora Control.  <b>NOTE:</b> Although the ABC has basic compatibility with all Aurora, new product features may not be available on older AID Tools. To simplify the basic compatibility ensure the version of AID is at least the same or greater than the ABC software version.	For Service (Ver. 1.xx or greater)

Add On Thermostats and Zoning	Description	Aurora 'Base'	Aurora 'Advanced'
 <b>TP32U03YRK/04YRK - MonoChrome Traditional Y1, Y2 Thermostat</b>	Elite Stat with full English fault codes and alerts, traditional Y1, Y2 thermostat	Optional	
 <b>TP32S01YRK/02YRK - Traditional Y1, Y2 Thermostat</b>	Traditional Y1, Y2 thermostat	Optional	
<b>IntelliZone® Zoning Compatibility</b>	IntelliZone® is a non-communicating zoning system requiring Y1, Y2 signals and controls the ECM blower motor directly.	Optional (ECM Preferred)	Optional (IntelliZone2 Preferred)

## The Aurora Control System cont.

### Aurora 'Base' Control



**NOTE:** Refer to the Aurora Base Control Application and Troubleshooting Guide and the Instruction Guide: Aurora Interface and Diagnostics (AID) Tool for additional information.

### Control Features

Software ABC Standard Version 2.0

#### Single or Dual Capacity Compressors

Either single or dual capacity compressors can be operated.

### Other Control Features

- Random start at power up
- Anti-short cycle protection
- High and low pressure cutouts
- Loss of charge
- Water coil freeze detection
- Over/under voltage protection
- Load shed
- Emergency shutdown
- Hot gas reheat operation (where applicable)
- Diagnostic LED
- Test mode push button switch
- Two auxiliary electric heat outputs
- Alarm output
- Accessory output with N.O. and N.C.
- Modbus communication (master)
- Modbus communication (slave)

### Field Selectable Options via Hardware

**DIP Switch (SW1)** – Test/Configuration Button (See SW1 Operation Table)

#### Test Mode

The control is placed in the test mode by holding the push button switch SW1 for 2 - 5 seconds. In test mode most of the control timings will be shortened by a factor of sixteen (16). LED3 (green) will flash at 1 second on and 1 second off. Additionally, when entering test mode LED1 (red) will flash the last lockout one time. Test mode will automatically time out after 30 minutes. Test mode can be exited by pressing and holding the SW1 button for 2 to 5 seconds or by cycling the power. **NOTE:** Test mode will automatically be exited after 30 minutes.

### Reset Configuration Mode

The control is placed in reset configuration mode by holding the push button switch SW1 for 50 to 60 seconds. This will reset all configuration settings and the EEPROM back to the factory default settings. LED3 (green) will turn off when entering reset configuration mode. Once LED3 (green) turns off, release SW1 and the control will reset.

### DIP Switch (SW2)

- SW2-1** FP1 Selection – Low water coil temperature limit setting for freeze detection. On = 30°F; Off = 15°F.
- SW2-2** FP2 Selection – On = 30°F; Off = N/A
- SW2-3** RV – O/B - thermostat type. Heat pump thermostats with "O" output in cooling or "B" output in Heating can be selected. On = O; Off = B.
- SW2-4 and 2-5** Access Relay Operation (P2)

Access Relay Operation	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON

**Cycle with Blower** - The accessory relay will cycle with the blower output.

**Cycle with Compressor** - The accessory relay will cycle with the compressor output.

**Water Valve Slow Opening** - The accessory relay will cycle and delay both the blower and compressor output for 90 seconds.

**SW2-6** CC Operation – selection of single or dual capacity compressor. On = Single Stage; Off = Dual Capacity

**SW2-7** Lockout and Alarm Outputs (P2) – selection of a continuous or pulsed output for both the LO and ALM Outputs. On = Continuous; Off = Pulsed

**SW2-8** Future Use

### Alarm Jumper Clip Selection

From the factory, ALM is connected to 24 VAC via JW2. By cutting JW2, ALM becomes a dry contact connected to ALG.

## The Aurora 'Base' Control System cont.

### Safety Features

The following safety features are provided to protect the compressor, heat exchangers, wiring and other components from damage caused by operation outside of design conditions.

**Fuse** – a 3 amp automotive type plug-in fuse provides protection against short circuit or overload conditions.

**Anti-Short Cycle Protection** – 4 minute anti-short cycle protection for the compressor.

**Random Start** – 5 to 80 second random start upon power up.

**Fault Retry** – in the fault condition, the control will stage off the outputs and then "try again" to satisfy the thermostat Y input call. Once the thermostat input calls are satisfied, the control will continue on as if no fault occurred. If 3 consecutive faults occur without satisfying the thermostat Y input call, then the control will go to Lockout mode.

**Lockout** – when locked out, the blower will operate continuously, and PSC blower motor output will remain on. The Alarm output (ALM) and Lockout output (L) will be turned on. The fault type identification display LED1 (Red) shall flash the fault code. To reset lockout conditions with SW2-8 On, thermostat inputs "Y1", "Y2", and "W" must be removed for at least 3 seconds. To reset lockout conditions with SW2-8 Off, thermostat inputs "Y1", "Y2", "W", and "DH" must be removed for at least 3 seconds. Lockout may also be reset by turning power off for at least 30 seconds or by enabling the emergency shutdown input for at least 3 seconds.

**High Pressure** – fault is recognized when the Normally Closed High Pressure Switch, P4-9/10 opens, no matter how momentarily. The High Pressure Switch is electrically in series with the Compressor Contactor and serves as a hard-wired limit switch if an overpressure condition should occur.

**Low Pressure** - fault is recognized when the Normally Closed Low Pressure Switch, P4-7/8 is continuously open for 30 seconds. Closure of the LPS any time during the 30 second recognition time restarts the 30 second continuous open requirement. A continuously open LPS shall not be recognized during the 2 minute startup bypass time.

**Loss of Charge** – fault is recognized when the Normally Closed Low Pressure Switch, P4-7/8 is open prior to the compressor starting.

**Freeze Detection (Coax)** - set points shall be either 30°F or 15°F. When the thermistor temperature drops below the selected set point, the control shall begin counting down the 30 seconds delay. If the thermistor value rises above the selected set point, then the count should reset. The resistance value must remain below the selected set point for the entire length of the appropriate delay to be recognized as a fault. This fault will be ignored for the initial 2 minutes of the compressor run time.

**Over/Under Voltage Shutdown** - An over/under voltage condition exists when the control voltage is outside the range of 18 VAC to 30 VAC. If the over/under voltage shutdown lasts for 15 minutes, the lockout and alarm relay will be energized. Over/under voltage shutdown is self-resetting in that if the voltage comes back within range of 18 VAC to 30 VAC for at least 0.5 seconds, then normal operation is restored.

### Operation Description

**Power Up** - The unit will not operate until all the inputs and safety controls are checked for normal conditions. The unit has a 5 to 80 second random start delay at power up. Then the compressor has a 4 minute anti-short cycle delay after the random start delay.

Standby In standby mode, Y1, Y2, W, DH, and G are not active. Input O may be active. The blower and compressor will be off.

### Heating Operation

**Heating, 1st Stage (Y1)** - The blower is started immediately and the compressor is energized 10 seconds after the Y1 input is received.

**Heating, 2nd Stage (Y1, Y2)** - The compressor will be staged to full capacity 20 seconds after Y2 input is received. The ECM blower will shift to high speed 15 seconds after the Y2 input is received.

**Heating, 3rd Stage (Y1, Y2, W)** - The hot water pump is de-energized and the first stage of electric heat is energized 10 seconds after the W command is received. If the demand continues the second stage of electric heat will be energized after 5 minutes.

**Emergency Heat (W Only)** - When the unit is matched with an air handler listed in the Air Handler Compatibility table, the thermostat will send the "W" input to the air handler's control board. The blower is started on high speed, and the first stage of resistance heat is energized 10 seconds after the "W" input. Continuing demand will engage the additional stages of resistance heat 90 seconds after the first stage.

**Blower (G)** - The blower will start immediately upon receiving a thermostat G command. If there are no other commands from the thermostat the ECM will run on "G" speed until the G command is removed. Regardless of blower input (G) from the thermostat, the blower will remain on for 30 seconds at the end of each heating cycle.

### Cooling Operation

In all cooling operations, the reversing valve directly tracks the O input. Thus, anytime the O input is present, the reversing valve will be energized.

**Cooling, 1st Stage (Y1, O)** - The blower is started immediately and the compressor is energized 10 seconds after the Y1 input is received.

**Cooling, 2nd Stage (Y1, Y2, O)** - The compressor will be staged to full capacity 20 seconds after Y2 input is received. The ECM blower will shift to high speed 15 seconds after the Y2 input is received.

## The Aurora 'Base' Control System cont.

**Blower (G)** - The blower will start immediately upon receiving a thermostat G command. If there are no other commands from the thermostat the ECM will run on "G" speed until the G command is removed. Regardless of blower input (G) from the thermostat, the blower will remain on for 30 seconds at the end of each heating, cooling, and emergency heat cycle.

**Emergency Shutdown** - Four (4) seconds after a valid ES input, P2-7 is present, all control outputs will be turned off and remain off until the emergency shutdown input is no longer present. The first time that the compressor is started after the control exits the emergency shutdown mode, there will be an anti-short cycle delay followed by a random start delay. Input must be tied to common to activate.

**Load Shed** - The LS input disables all outputs with the exception of the blower output. When the LS input has been cleared, the anti-short cycle timer and random start timer will be initiated. Input must be tied to common to activate.

### Aurora 'Base' Control LED Displays

These three LEDs display the status, configuration, and fault codes for the control. These can also be read in plain English via the Aurora AID Tool.

#### Status LED (LED3, Green)

Description of Operation	Fault LED, Green
Normal Mode	ON
Control is Non-functional	OFF
Test Mode	Slow Flash
Lockout Active	Fast Flash
Dehumidification Mode	Flash Code 2
(Future Use)	Flash Code 3
(Future Use)	Flash Code 4
Load Shed	Flash Code 5
ESD	Flash Code 6
(Future Use)	Flash Code 7

#### Configuration LED (LED2, Yellow)

Description of Operation	Configuration LED, Yellow
No Software Overwritten	Flashing ECM Setting
DIP Switch was Overwritten	Slow Flash
ECM Configuration Mode	Fast Flash

#### Fault LED (LED1, Red)

Red Fault LED		LED Flash Code*	Lockout	Reset/Remove
ABC Basic Faults	Normal - No Faults	OFF	—	
	Fault - Input	1	No	Auto
	Fault - High Pressure	2	Yes	Hard or Soft
	Fault - Low Pressure	3	Yes	Hard or Soft
	Fault - Freeze Detection FP2	4	Yes	Hard or Soft
	Fault - Freeze Detection FP1	5	Yes	Hard or Soft
	Fault - Condensate Overflow	7	Yes	Hard or Soft
	Fault - Over/Under Voltage	8	No	Auto
	Fault - FP1 & FP2 Sensor Error	11	Yes	Hard or Soft

**NOTE:** All codes >11 use long flash for tens digit and short flash for the ones digit. 20, 30, 40, 50, etc. are skipped.


### Aurora Interface and Diagnostics (AID) Tool

The Aurora Interface and Diagnostics (AID) Tool is a device that is a member of the Aurora network. The AID Tool is used to troubleshoot equipment which uses the Aurora control via Modbus RTU communication. The AID Tool provides diagnostics, fault management, ECM setup, and system

configuration capabilities to the Aurora family of controls. An AID Tool is recommended, although not required, for ECM airflow settings. The AID Tool simply plugs into the exterior of the cabinet in the AID Tool port.



### ABC Control Board Layout



## Reference Calculations

Heating Calculations:	Cooling Calculations:
$LWT = EWT - \frac{HE}{GPM \times 500}$	$LWT = EWT + \frac{HR}{GPM \times 500}$
$LAT = EAT + \frac{HC}{CFM \times 1.08}$	$LAT (DB) = EAT (DB) - \frac{SC}{CFM \times 1.08}$
$TH = HC + HW$	$LC = TC - SC$
	$S/T = \frac{SC}{TC}$

## Legend

### ABBREVIATIONS AND DEFINITIONS:

CFM = airflow, cubic feet/minute  
 EWT = entering water temperature, Fahrenheit  
 GPM = water flow in gallons/minute  
 WPD = water pressure drop, PSI and feet of water  
 EAT = entering air temperature, Fahrenheit  
 (dry bulb/wet bulb)  
 HC = air heating capacity, MBTUH  
 TC = total cooling capacity, MBTUH  
 SC = sensible cooling capacity, MBTUH  
 KW = total power unit input, kilowatts  
 HR = total heat of rejection, MBTUH

HE = total heat of extraction, MBTUH  
 HW = hot water generator capacity, MBTUH  
 EER = Energy Efficiency Ratio  
 = BTU output/Watt input  
 COP = Coefficient of Performance  
 = BTU output/BTU input  
 LWT = leaving water temperature, °F  
 LAT = leaving air temperature, °F  
 TH = total heating capacity, MBTUH  
 LC = latent cooling capacity, MBTUH  
 S/T = sensible to total cooling ratio

## Operating Limits

Operating Limits	Cooling	Heating
Air Limits		
Minimum ambient air, DB	-10°F [-23.3°C]	-10°F [-23.3°C]
Rated ambient air, DB	80.0 [26.7°C]	70°F [21.1°C]
Maximum ambient air, DB	120 [48.8°C]	85°F [29°C]
Water Limits		
Minimum entering water	30°F [-1°C]	20°F [-6.7°C]
Normal entering water	50-110°F [10-43°C]	30-70°F [-1 to 21°C]
Maximum entering water	120°F [49°C]	90°F [32°C]
Normal water flow	1.5 to 3.0 gpm per ton [1.6 to 3.2 l/m per kW]	

**NOTES:** Minimum/maximum limits are only for start-up conditions, and are meant for bringing the space up to occupancy temperature. Units are not designed to operate at the minimum/maximum conditions on a regular basis. The operating limits are dependent upon three primary factors: 1) water temperature, 2) return air temperature, and 3) ambient temperature. When any of the factors are at the minimum or maximum levels, the other two factors must be at the normal level for proper and reliable unit operation.

The diagram illustrates the electrical wiring for the Flow Center unit. It includes the following components and connections:



- Ext Pump:** A dashed box labeled "Ext Pump" contains two pumps and a ground symbol. It is connected to the PB1 terminal block via Yellow (8) and Gray (9) wires. A Note 1 points to the ground connection.
- PB1:** A terminal block with two terminals, 1 and 2. Terminal 1 is connected to the Yellow (8) wire from the Ext Pump and the Violet (6) wire from the 5A Circuit Breaker. Terminal 2 is connected to the Gray (9) wire from the Ext Pump and the Violet (7) wire from the 5A Circuit Breaker.
- Ground Lug:** A ground symbol connected to the Green (17) wire, which is also connected to the Ground Lug.
- Unit Power Supply:** A box labeled "Unit Power Supply 208-230/60/1" with terminals T2, T1, L2, and L1. It is connected to the Violet (6) and Violet (7) wires from the PB1 terminal block. The ground symbol is connected to the L2 terminal.
- Compressor:** A circle labeled "Compressor" with terminals S, C, and R. It is connected to the Blue wire (Cap), Tan (16) wire, and Red wire. The Black wire is connected to the T1 terminal of the Unit Power Supply.
- Crankcase Heater:** A resistor symbol connected to the Black wire from the T1 terminal of the Unit Power Supply and the Black (3) wire from the Compressor.
- Other Connections:**
  - The Violet (6) wire is connected to a 5A Circuit Breaker.
  - The Violet (7) wire is connected to another 5A Circuit Breaker.
  - The Black (2) wire is connected to the T2 terminal of the Unit Power Supply.
  - The Black (1) wire is connected to the RP terminal of the 5A Circuit Breaker.
  - The Red (11) wire is connected to the FP terminal of the 5A Circuit Breaker.
  - The Red (12) wire is connected to the T1 terminal of the Unit Power Supply.




Aurora LED Flash Codes			
<b>Slow Flash</b>	1 second on and 1 second off		
<b>Fast Flash</b>	100 milliseconds on and 100 milliseconds off		
<b>Flash Code</b>	100 milliseconds on and 400 milliseconds off with a 2 second pause before repeating		
<b>Random Start Alerting (Alternating Colors)</b>		<b>Configuration LED (LED2, Yellow)</b>	
Status LED (LED1, Green)	Fast Flash	No Software Override	OFF
Configuration LED (LED2, Yellow)	Fast Flash	DIP Switch Override	Slow Flash
Fault LED (LED3, Red)	Fast Flash		
<b>Fault LED (LED1, Red)</b>		<b>Status LED (LED3, Green)</b>	
Normal Mode	OFF	Normal Mode	ON
Input Fault Lockout	Flash Code 1	Control is Non-Functional	OFF
High Pressure Lockout	Flash Code 2	Test Mode	Slow Flash
Low Pressure Lockout	Flash Code 3	Lockout Active	Fast Flash
Future Use	Flash Code 4	Dehumidification Mode	Flash Code 2
Freeze Detection – FP1	Flash Code 5	Future Use	Flash Code 3
Reserved	Flash Code 6	Future Use	Flash Code 4
Condensate Overflow Lockout	Flash Code 7	Load Shed	Flash Code 5
Over/Under Voltage Shutdown	Flash Code 8	ESD	Flash Code 6
Future Use	Flash Code 9	Future Use	Flash Code 7
Future Use	Flash Code 10		
FP1 and FP2 Sensor Error	Flash Code 11		

Aurora Timing Events		
Event	Normal Mode	Test Mode
Random Start Delay	5 to 80 seconds	1 second
Compressor On Delay	5 seconds	< 1 second
Compressor Minimum On Time	2 minutes	5 seconds
Compressor Short Cycle Delay	4 minutes	15 seconds
Blower Off Delay	30 seconds	2 seconds
Fault Recognition Delay - High Pressure	Less than 1 second	Less than 1 second
Start-Up Bypass - Low Pressure	2 minutes	30 seconds
Fault Recognition Delay - Low Pressure	30 seconds	30 seconds
Start-Up Bypass - Low Water Coil Limit	2 minutes	30 seconds
Fault Recognition Delay - Low Water Coil Limit	30 seconds	30 seconds
Fault Recognition Delay - Condensate Overflow	30 seconds	30 seconds
Thermostat Call Recognition Time	2 seconds	2 seconds
Water Valve Slow Open Delay	90 seconds	90 seconds

ABC SW2 Accessory Relay		
DESCRIPTION	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON




1 - Flow Center may be either factory or field installed.  
2 - Field installed SPST relay required for dual fuel applications



The diagram illustrates the electrical wiring for the Flow Center unit. Key components and their connections include:

- Ext Pump:** A 1/2 hp Total pump (208-230/60/1) is connected to the main power lines. A note indicates that the pump is grounded.
- PB1:** A pressure switch with two terminals (1 and 2) is connected to the main power lines. Terminal 1 is connected to the Yellow (8) wire, and terminal 2 is connected to the Gray (9) wire.
- Grounding:** A Ground Lug is connected to the Green (17) wire. The Compressor and Unit Power Supply are also grounded.
- Circuit Breakers:** Two 5A circuit breakers are used to protect the main power lines. One is connected to the Violet (6) wire, and the other is connected to the Violet (7) wire.
- Compressor:** The compressor motor is connected to the main power lines. It has three windings: Run Winding (Red), Active (Pink), and Start (Black). The Start winding is connected to the Black (2) wire. The Run Winding is connected to the Black (1) wire. The Active winding is connected to the Black (3) wire.
- Unit Power Supply:** A 208-230/60/1 unit power supply is connected to the main power lines. It has two terminals (T1 and T2) and a common terminal (CC). T1 is connected to the Black (1) wire, T2 is connected to the Black (2) wire, and CC is connected to the Black (3) wire.
- Crankcase Heater:** A heater is connected to the main power lines. It has two terminals (L1 and L2) and a common terminal (CC). L1 is connected to the Black (1) wire, L2 is connected to the Black (2) wire, and CC is connected to the Black (3) wire.
- Wiring:** The main power lines are color-coded: Yellow (8), Gray (9), Green (17), Violet (6), Violet (7), Black (1), Black (2), Black (3), Red (11), and Red (12).







# Wiring Schematics cont.

## Dual Capacity Split with GeoStart - 208-230/60/1 cont.

Aurora LED Flash Codes			
Slow Flash	1 second on and 1 second off		
Fast Flash	100 milliseconds on and 100 milliseconds off		
Flash Code	100 milliseconds on and 400 milliseconds off with a 2 second pause before repeating		
Random Start Delay (Alternating Colors)		Configuration LED (LED2, Yellow)	
Status LED (LED1, Green)	Fast Flash	No Software Override	OFF
Configuration LED (LED2, Yellow)	Fast Flash	DIP Switch Override	Slow Flash
Fault LED (LED3, Red)	Fast Flash		
Fault LED (LED1, Red)		Status LED (LED3, Green)	
Normal Mode	OFF	Normal Mode	ON
Input Fault Lockout	Flash Code 1	Control is Non-Functional	OFF
High Pressure Lockout	Flash Code 2	Test Mode	Slow Flash
Low Pressure Lockout	Flash Code 3	Lockout Active	Fast Flash
Future Use	Flash Code 4	Dehumidification Mode	Flash Code 2
Freeze Detection - FP1	Flash Code 5	Future Use	Flash Code 3
Reserved	Flash Code 6	Future Use	Flash Code 4
Condensate Overflow Lockout	Flash Code 7	Load Shed	Flash Code 5
Over/Under Voltage Shutdown	Flash Code 8	ESD	Flash Code 6
Future Use	Flash Code 9	Future Use	Flash Code 7
Future Use	Flash Code 10		
FP1 and FP2 Sensor Error	Flash Code 11		


Aurora Timing Events		
Event	Normal Mode	Test Mode
Random Start Delay	5 to 80 seconds	1 second
Compressor On Delay	5 seconds	< 1 second
Compressor Minimum On Time	2 minutes	5 seconds
Compressor Short Cycle Delay	4 minutes	15 seconds
Blower Off Delay	30 seconds	2 seconds
Fault Recognition Delay - High Pressure	Less than 1 second	Less than 1 second
Start-Up Bypass - Low Pressure	2 minutes	30 seconds
Fault Recognition Delay - Low Pressure	30 seconds	30 seconds
Start-Up Bypass - Low Water Coil Limit	2 minutes	30 seconds
Fault Recognition Delay - Low Water Coil Limit	30 seconds	30 seconds
Fault Recognition Delay - Condensate Overflow	30 seconds	30 seconds
Thermostat Call Recognition Time	2 seconds	2 seconds
Water Valve Slow Open Delay	90 seconds	90 seconds

ABC SW2 Accessory Relay		
DESCRIPTION	SW2-4	SW2-5
Cycle with Blower	ON	ON
Cycle with Compressor	OFF	OFF
Water Valve Slow Opening	ON	OFF
Cycle with Comm. T-stat Hum Cmd	OFF	ON



### Notes

- 1 - Flow Center may be either factory or field installed.
- 2 - Field installed SPST relay required for dual fuel applications.



## Refrigeration

### Leak Testing

The refrigeration line set must be pressurized and checked for leaks before purging and charging the unit. To pressurize the line set, attach refrigerant gauges to the service ports and add an inert gas (nitrogen or dry carbon dioxide) until pressure reaches 60 to 90 PSIG. Never use oxygen or acetylene to pressure test. Use an electronic leak detector or a good quality bubble solution to detect leaks on all connections made in the field. Check the service valve ports and stem for leaks and all connections made in the field. If a leak is found, repair it and repeat the above steps. For safety reasons do not pressurize the system above 150 psi. Purge pressure from line set. The system is now ready for evacuating and charging.

### System Evacuation

Ensure that the line set and air coil are evacuated before opening service valves to the split unit. The line set must be evacuated to at least 200 microns to remove the moisture and air that may still be in the line set and coil. Evacuate the system through both service ports to prevent false readings on the gauge because of pressure drop through service ports.

### Charge Amount When Using YAH Air Handler

The Affinity Split is shipped with a factory pre-charge. This volume of refrigerant is not sufficient to run the system and additional refrigerant must be added. If using an YAH Air Handler please refer to the table in this section for charge amounts to be added. The "Factory Charge" column is the charge amount the compressor section/split is shipped with from the factory. The "Charge Amount with YAH Air Handler" column is the total amount of charge for the YAH Air Handler + Compressor section/split. This column does not factor in additional refrigerant needed for the line set. The installer of the system must add charge appropriately for the specific length of the line set. A 3/8 in. liquid line is calculated at 0.50 oz. of charge per linear foot, and a 1/2 in. liquid line is calculated at 1.0 oz. of charge per linear foot using R-410A refrigerant. The suction line will not hold "liquid" and should be ignored for the charge calculation.

Example: YAST038/YAH036 with 20 ft. of 3/8 in. liquid line. Remember that when using the YAH Air Handler, the column "Charge Amount with YAH Air Handler" will be used. Now calculate for the additional 20 ft. in set. Additional refrigerant to be added = (20 ft. x 0.5 oz.) = 10 oz.

Solution: 10 oz. should be added to the recommended charge of 86 oz. found in the "Charge Amount with YAH Air Handler" column for a total charge of 96 oz.

After initial charge, the system should be operated and the system subcooling and superheat verified to the Unit Operating Parameters table.

If an air handler manufactured by others is used then refrigerant should be added to the Affinity Split factory pre-charge. Refrigerant should be added for liquid line length. This should result in a slightly under-charged system exhibiting low subcooling and high superheat. As charge is added, the subcooling should rise and the superheat should fall.

### Charging the System

Charge Method – After purging and evacuating the line set, fully open the service valves counterclockwise. Add R-410A (liquid) into the liquid line service port until the pressure in the system reaches approximately 200 PSIG. Never add liquid refrigerant into the suction side of a compressor. Start the unit and measure superheat and subcooling. Keep adding refrigerant until the unit meets the superheat and subcooling values in the Operating Parameters tables.

## Checking Superheat and Subcooling

### Determining Superheat

1. Measure the temperature of the suction line at the point where the expansion valve bulb is clamped.
2. Determine the suction pressure in the suction line by attaching refrigeration gauges to the schrader connection on the suction side of the compressor.
3. Convert the pressure obtained in Step 2 to the saturation temperature by using the Pressure Temperature Conversion Chart for R-410A.
4. Subtract the temperature obtained in Step 3 from Step 1. The difference is the amount of superheat for the unit. Refer to the Operating Parameters tables for superheat ranges at specific entering water conditions.

### Superheat Adjustment

TXVs are factory set to a specific superheat; however, the superheat should be adjusted for the application. To adjust the TXV to other superheat settings:

1. Remove the seal cap from the bottom of the valve.
2. Turn the adjustment screw clockwise to increase superheat and counterclockwise to decrease superheat. One complete 360° turn changes the superheat approximately 3-4°F, regardless of refrigerant type. You may need to allow as much as 30 minutes after the adjustment is made for the system to stabilize.
3. Once the proper superheat setting has been achieved, replace and tighten the seal cap.



**WARNING:** There are 8 total (360°) turns on the superheat adjustment stem from wide open to fully closed. When adjusting the superheat stem clockwise (superheat increase) and the stop is reached, any further clockwise turning adjustment will damage the valve.

## Refrigeration cont.

### Determining Subcooling

1. Measure the temperature of the liquid line on the small refrigerant line (liquid line) just outside the split cabinet. This location will be adequate for measurement in both modes unless a significant temperature drop in the liquid line is anticipated.
2. Measure the liquid line pressure by attaching refrigerant gauges to the schrader connection on the liquid line service valve.
3. Convert the pressure obtained in Step 2 to the saturation temperature by using the Pressure Temperature Conversion Chart for R-410A.
4. Subtract the temperature in Step 1 from the temperature in Step 3. The difference will be the subcooling value for that unit. Refer to the Operating Parameters tables for subcooling ranges at specific enter water conditions.

## Line Set Sizes

Unit Size	Air Handler	20 feet		40 feet		60 feet		Factory Charge (oz.)	*Charge Amount with YAH Air Handler (oz.)
		Suction	Liquid	Suction	Liquid	Suction	Liquid		
026	YAH026	5/8" OD	3/8" OD	3/4" OD	3/8" OD	3/4" OD	1/2" OD	52	74
038	YAH036	3/4" OD	3/8" OD	3/4" OD	3/8" OD	3/4" OD	1/2" OD	56	86
049	YAH048	3/4" OD	3/8" OD	7/8" OD	3/8" OD	7/8" OD	1/2" OD	90	115
064	YAH060	7/8" OD	1/2" OD	7/8" OD	1/2" OD	1-1/8" OD	1/2" OD	92	112
072	YAH060	7/8" OD	1/2" OD	7/8" OD	1/2" OD	1-1/8" OD	1/2" OD	104	132

**NOTES:** \* The "Charge Amount with YAH Air Handler" column is based on the charge amount for an YAH Air Handler + Compressor Section Split.

Additional charge will have to be added accordingly for line set length.

After charge is added, adjustments can be made to get appropriate subcooling and superheat.

Additional charge for R-410A is 0.50 oz. per ft. for 3/8 in. and 1.0 oz. per ft. for 1/2 in. tube.

4/16/10

## Pressure/Temperature Conversion Chart for R-410A

PRESSURE (PSIG)	TEMP °F	PRESSURE (PSIG)	TEMP °F	PRESSURE (PSIG)	TEMP °F	PRESSURE (PSIG)	TEMP °F	PRESSURE (PSIG)	TEMP °F
60	8.5	180	63.5	300	96.3	420	120.6	540	140.0
62	9.9	182	64.2	302	96.8	422	120.9	542	140.3
64	11.2	184	64.8	304	97.2	424	121.3	544	140.6
66	12.5	186	65.5	306	97.7	426	121.6	546	140.9
68	13.8	188	66.1	308	98.1	428	122.0	548	141.2
70	15.1	190	66.8	310	98.6	430	122.3	550	141.4
72	16.3	192	67.4	312	99.0	432	122.7	552	141.7
74	17.5	194	68.0	314	99.5	434	123.0	554	142.0
76	18.7	196	68.7	316	99.9	436	123.4	556	142.3
78	19.8	198	69.3	318	100.4	438	123.7	558	142.6
80	21.0	200	69.9	320	100.8	440	124.1	560	142.9
82	22.1	202	70.5	322	101.2	442	124.4	562	143.2
84	23.2	204	71.1	324	101.7	444	124.8	564	143.5
86	24.3	206	71.7	326	102.1	446	125.1	566	143.7
88	25.4	208	72.3	328	102.5	448	125.4	568	144.0
90	26.5	210	72.9	330	103.0	450	125.8	570	144.3
92	27.5	212	73.5	332	103.4	452	126.1	572	144.6
94	28.6	214	74.1	334	103.8	454	126.5	574	144.9
96	29.6	216	74.7	336	104.2	456	126.8	576	145.1
98	30.6	218	75.3	338	104.7	458	127.1	578	145.4
100	31.6	220	75.8	340	105.1	460	127.5	580	145.7
102	32.6	222	76.4	342	105.5	462	127.8	582	146.0
104	33.5	224	77.0	344	105.9	464	128.1	584	146.2
106	34.5	226	77.5	346	106.3	466	128.5	586	146.5
108	35.4	228	78.1	348	106.7	468	128.8	588	146.8
110	36.4	230	78.7	350	107.2	470	129.1	590	147.1
112	37.3	232	79.2	352	107.6	472	129.4	592	147.3
114	38.2	234	79.8	354	108.0	474	129.8	594	147.6
116	39.1	236	80.3	356	108.4	476	130.1	596	147.9
118	40.0	238	80.9	358	108.8	478	130.4	598	148.2
120	40.9	240	81.4	360	109.2	480	130.7	600	148.4
122	41.7	242	81.9	362	109.6	482	131.1	602	148.7
124	42.6	244	82.5	364	110.0	484	131.4	604	149.0
126	43.4	246	83.0	366	110.4	486	131.7	606	149.2
128	44.3	248	83.5	368	110.8	488	132.0	608	149.5
130	45.1	250	84.1	370	111.2	490	132.3		
132	45.9	252	84.6	372	111.6	492	132.7		
134	46.7	254	85.1	374	112.0	494	133.0		
136	47.5	256	85.6	376	112.3	496	133.3		
138	48.3	258	86.1	378	112.7	498	133.6		
140	49.1	260	86.6	380	113.1	500	133.9		
142	49.9	262	87.1	382	113.5	502	134.2		
144	50.7	264	87.7	384	113.9	504	134.5		
146	51.5	266	88.2	386	114.3	506	134.9		
148	52.2	268	88.7	388	114.7	508	135.2		
150	53.0	270	89.2	390	115.0	510	135.5		
152	53.7	272	89.6	392	115.4	512	135.8		
154	54.5	274	90.1	394	115.8	514	136.1		
156	55.2	276	90.6	396	116.2	516	136.4		
158	55.9	278	91.1	398	116.5	518	136.7		
160	56.6	280	91.6	400	116.9	520	137.0		
162	57.4	282	92.1	402	117.3	522	137.3		
164	58.1	284	92.6	404	117.6	524	137.6		
166	58.8	286	93.0	406	118.0	526	137.9		
168	59.5	288	93.5	408	118.4	528	138.2		
170	60.2	290	94.0	410	118.7	530	138.5		
172	60.8	292	94.5	412	119.1	532	138.8		
174	61.5	294	94.9	414	119.5	534	139.1		
176	62.2	296	95.4	416	119.8	536	139.4		
178	62.9	298	95.8	418	120.2	538	139.7		

## Unit Startup

### Before Powering Unit, Check the Following:

**NOTE:** Remove and discard the compressor hold down shipping bolt located at the front of the compressor mounting bracket.

- High voltage is correct and matches nameplate.
- Fuses, breakers and wire size correct.
- Low voltage wiring complete.
- Piping completed and water system cleaned and flushed.
- Air is purged from closed loop system.
- Isolation valves are open, water control valves or loop pumps wired.
- Condensate line open and correctly pitched.
- Transformer switched to 208V if applicable.
- Dip switches are set correctly.
- Blower rotates freely.
- Blower speed is correct.
- Air filter/cleaner is clean and in position.
- Service/access panels are in place.
- Return air temperature is between 50-80°F heating and 60-95°F cooling.
- Check air coil cleanliness to ensure optimum performance. Clean as needed according to maintenance guidelines. To obtain maximum performance the air coil should be cleaned before startup. A 10% solution of dishwasher detergent and water is recommended for both sides of coil, a thorough water rinse should follow.

11. First stage heating will energize after a time delay.
12. Check the temperature of both the supply and discharge water (see the Unit Operating Parameters tables).
13. Check for an air temperature rise of 12°F to 35°F across the air coil, depending on the fan speed and entering water temperature.
14. If auxiliary electric heaters are installed, increase the heating setpoint until the electric heat banks are sequenced on. All stages of the auxiliary heater should be sequenced on when the thermostat is in the Emergency Heat mode. Check amperage of each element.
15. Adjust the heating setpoint below room temperature and verify that the compressor and water valve or loop pumps deactivate.
16. During all testing, check for excessive vibration, noise or water leaks. Correct or repair as required.
17. Set system to desired normal operating mode and set temperature to maintain desired comfort level.
18. Instruct the owner/operator in the proper operation of the thermostat and system maintenance.

**NOTE:** Be certain to fill out and forward all warranty registration papers.

### Startup Steps

**NOTE:** Complete the Equipment Start-Up/Commissioning Check Sheet during this procedure. Refer to thermostat operating instructions and complete the startup procedure. Verify that the compressor shipping bolt has been removed.

1. Initiate a control signal to energize the blower motor.
2. Initiate a control signal to place the unit in the cooling mode. Cooling setpoint must be set below room temperature.
3. First stage cooling will energize after a time delay.
4. Be sure that the compressor and water control valve or loop pump(s) are activated.
5. Verify that the water flow rate is correct by measuring the pressure drop through the heat exchanger using the P/T plugs and comparing to unit performance data in catalog.
6. Check the temperature of both the supply and discharge water (see the Unit Operating Parameters tables).
7. Check for an air temperature drop of 15°F to 25°F across the air coil, depending on the fan speed and entering water temperature.
8. Decrease the cooling set point several degrees and verify high-speed blower operation.
9. Adjust the cooling setpoint above the room temperature and verify that the compressor and water valve or loop pumps deactivate.
10. Initiate a control signal to place the unit in the heating mode. Heating set point must be set above room temperature.

## Operating Parameters

### First Stage Operation

Cooling -- No Desuperheater									
Entering Water Temp °F	Water Flow GPM/Ton	YAST026 thru YAST064		YAST072		YAST026 thru YAST072			
		Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Superheat	Subcooling	Water Temp Rise °F	Air Temp Drop °F DB
50	1.5	130-150	193-230	130-150	200-245	8-16	7-14	15-21	18-24
	3.0	128-153	190-230	125-140	205-240	8-16	3-10	9-14	18-25
70	1.5	130-150	238-282	135-150	240-280	6-16	4-16	12-18	18-25
	3.0	130-155	238-262	125-145	245-270	6-18	5-11	5-10	18-24
90	1.5	133-148	308-340	130-155	300-365	7-16	6-18	10-16	19-25
	3.0	138-153	303-333	130-165	305-350	7-18	7-14	5-10	17-22

Heating -- No Desuperheater									
Entering Water Temp °F	Water Flow GPM/Ton	YAST026 thru YAST064		YAST072		YAST026 thru YAST072			
		Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Superheat	Subcooling	Water Temp Drop °F	Air Temp Rise °F DB
30	1.5	78-100	275-325	85-105	325-385	6-11	4-16	5-9	20-29
	3.0	78-110	285-325	90-120	335-375	6-11	4-16	3-7	20-32
50	1.5	105-120	305-350	100-130	340-400	5-12	4-16	5-12	24-32
	3.0	110-125	305-355	110-125	345-395	9-15	2-14	4-9	20-34
70	1.5	140-155	305-355	130-165	370-430	5-12	2-14	8-12	24-39
	3.0	145-160	330-360	140-160	375-425	7-17	7-15	4-10	24-39

### Second Stage Operation

Cooling -- No Desuperheater									
Entering Water Temp °F	Water Flow GPM/Ton	YAST026 thru YAST064		YAST072		YAST026 thru YAST072			
		Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Superheat	Subcooling	Water Temp Rise °F	Air Temp Drop °F DB
50	1.5	120-140	200-245	105-150	210-270	7-17	6-14	15-21	19-26
	3.0	115-140	195-290	110-130	215-260	7-15	4-11	9-14	20-24
70	1.5	121-136	265-310	105-150	280-350	9-15	6-18	12-18	19-25
	3.0	123-139	265-310	110-140	285-320	10-16	8-16	5-10	18-24
90	1.5	122-140	310-360	115-140	325-385	8-14	6-18	10-16	18-24
	3.0	123-139	310-350	120-135	330-355	8-14	7-15	5-10	17-23

Heating -- No Desuperheater									
Entering Water Temp °F	Water Flow GPM/Ton	YAST026 thru YAST064		YAST072		YAST026 thru YAST072			
		Suction Pressure PSIG	Discharge Pressure PSIG	Suction Pressure PSIG	Discharge Pressure PSIG	Superheat	Subcooling	Water Temp Drop °F	Air Temp Rise °F DB
30	1.5	72-89	295-350	70-100	320-370	7-18	10-20	5-9	18-24
	3.0	73-87	305-330	75-90	315-365	7-18	10-20	3-7	18-27
50	1.5	100-120	320-365	95-130	375-430	6-14	6-18	5-12	23-34
	3.0	105-120	355-365	100-125	370-420	6-14	6-18	4-9	20-37
70	1.5	142-158	360-380	130-165	400-470	6-12	4-15	8-12	28-38
	3.0	138-152	365-390	135-160	405-465	7-14	4-15	4-10	24-42

Cooling performance based on entering air temperatures of 80°F DB, 67°F WB.

Heating performance based on entering air temperature of 70°F DB.

## Pressure Drop

### Dual Capacity

Model	GPM	Pressure Drop (psi)				
		30°F	50°F	70°F	90°F	110°F
026 full load	4	1.4	1.3	1.2	1.1	1.0
	6	2.8	2.6	2.4	2.3	2.1
	8	4.7	4.4	4.1	3.8	3.5
	10	7.0	6.6	6.2	5.8	5.3
026 part load	3	0.8	0.7	0.7	0.7	0.6
	5	2.0	1.8	1.7	1.6	1.5
	7	3.6	3.4	3.2	3.0	2.8
	9	5.8	5.5	5.1	4.8	4.4
038 full load	5	1.2	1.2	1.1	1.0	1.0
	7	2.2	2.1	1.9	1.8	1.7
	9	3.4	3.2	3.0	2.8	2.6
	11	4.9	4.6	4.3	4	3.7
038 part load	4	0.9	0.8	0.8	0.7	0.7
	6	1.7	1.6	1.5	1.4	1.3
	8	2.8	2.6	2.5	2.3	2.1
	10	4.2	3.9	3.7	3.4	3.2
049 full load	6	1.2	1.2	1.1	1.0	1.0
	9	2.4	2.2	2.1	2.0	1.8
	12	3.9	3.6	3.4	3.2	2.9
	15	5.7	5.3	5	4.7	4.3
049 part load	5	0.9	0.9	0.8	0.8	0.7
	8	2.0	1.8	1.7	1.6	1.5
	11	3.4	3.1	2.9	2.8	2.5
	14	5.0	4.7	4.4	4.1	3.8
064 full load	8	1.8	1.7	1.6	1.4	1.3
	12	3.8	3.5	3.3	3.0	2.8
	16	6.5	6.0	5.6	5.2	4.8
	20	9.7	9.1	8.5	8.0	7.4
064 part load	6	1.0	0.9	0.9	0.8	0.8
	10	2.6	2.5	2.3	2.1	2.0
	14	5.0	4.7	4.4	4.1	3.8
	18	8.1	7.6	7.1	6.6	6.1
072 full load	12	3.2	3.0	2.8	2.6	2.4
	15	4.5	4.2	4.0	3.7	3.4
	18	6.0	5.7	5.3	4.9	4.6
	21	7.8	7.3	6.8	6.4	5.9
072 part load	10	2.3	2.1	2.0	1.9	1.7
	13	3.6	3.3	3.0	2.8	2.6
	16	5.0	4.6	4.3	4.0	3.7
	19	6.5	6.2	5.8	5.4	5.0

5/30/06

## Compressor Resistance

### Compressor Resistance Chart (Ohms)

Model	208-230/60/1	
	Run	Start
026	1.21-1.39	1.52-1.75
038	0.81-0.94	1.41-1.63
049	0.48-0.55	1.72-1.99
064	0.36-0.42	1.51-1.74
072	0.31-0.36	1.72-1.98

9/03/13

## Thermistor Resistance

### Thermistor Resistance Chart

Thermistor Temperature (°F)	Microprocessor Resistance (Ohms)
5	75757-70117
14	57392-53234
23	43865-40771
32	33809-31487
41	26269-24513
50	20570-19230
59	16226-15196
68	12889-12093
77	10310-9688
86	8300-7812
95	6723-6337
104	5480-5172
113	4490-4246
122	3700-3504
131	3067-2907
140	2554-2424
149	2149-2019

7/6/10

## Refrigerant Circuit Guideline

Symptom	Head Pressure	Suction Pressure	Compressor Amp Draw	Superheat	Subcooling	Air Temp. Differential	Water Temp. Differential
Under Charged System (Possible Leak)	Low	Low	Low	High	Low	Low	Low
Over Charged System	High	High	High	Normal	High	Normal/Low	Normal
Low Air Flow Heating	High	High	High	High/Normal	Low	High	Low
Low Air Flow Cooling	Low	Low	Low	Low/Normal	High	High	Low
Low Water Flow Heating	Low/Normal	Low/Normal	Low	Low	High	Low	High
Low Water Flow Cooling	High	High	High	High	Low	Low	High
High Air Flow Heating	Low	Low	Low	Low	High	Low	Low
High Air Flow Cooling	Low	High	Normal	High	Low	Low	Normal
High Water Flow Heating	Normal	Low	Normal	High	Normal	Normal	Low
High Water Flow Cooling	Low	Low	Low	Low	High	Normal	Low
Low Indoor Air Temperature Heating	Low	Low	Low	Normal	High	Normal	Normal/High
Low Indoor Air Temperature Cooling	Low	Low	Low	Normal/Low	High	Low	Low
High Indoor Air Temperature Heating	High	High	High	Normal/High	Normal/Low	Low	Normal
High Indoor Air Temperature Cooling	High	High	High	High	Low	Low	High
Restricted TXV (Check Service Advisory)	High	Low	Normal/Low	High	High	Low	Low
Insufficient Compressor (Possible Bad Valves)	Low	High	Low	High	Normal/High	Low	Low
TXV - Bulb Loss of Charge	Low	Low	Low	High	High	Low	Low
Scaled Coaxial Heat Exchanger Heating	Low	Low	Low	Normal/Low	High	Low	Low
Scaled Coaxial Heat Exchanger Cooling	High	High	High	Normal/Low	Low	Low	Low
Restricted Filter Drier	Check temperature difference (delta T) across filter drier.						

7/6/10

## Heat of Extraction/Rejection Data

Model		GPM	Heat of Extraction (kBtu/h)				Heat of Rejection (kBtu/h)				
			30°F	50°F	70°F	90°F	30°F	50°F	70°F	90°F	110°F
026	Part Load	3.0		13.1	17.6	21.5		23.5	22.9	21.8	
		5.0	9.4	13.8	18.6	22.6	21.7	23.6	23.0	21.7	20.2
		7.0	9.6	14.1	18.9	23.0	21.9	23.7	23.1	21.7	20.2
	Full Load	4.0		17.8	23.4	28.5		31.0	31.2	30.0	
		6.0	13.4	18.8	24.7	29.9	29.9	31.1	31.3	29.9	28.1
		8.0	13.6	19.3	25.1	30.5	30.1	31.2	31.3	29.9	28.1
038	Part Load	4.0		17.9	23.3	28.1		32.5	31.8	30.0	
		6.0	12.8	18.7	24.5	29.8	29.8	32.7	32.0	30.1	28.2
		8.0	13.9	19.7	25.2	29.8	30.3	33.1	32.4	30.4	28.5
	Full Load	5.0		25.1	31.5	36.1		44.8	45.1	42.8	
		7.0	18.7	26.2	33.2	38.6	41.8	45.2	45.7	43.6	41.0
		9.0	19.1	26.9	34.3	40.0	42.0	45.5	46.0	43.8	41.1
049	Part Load	5.0		24.0	29.5	33.7		44.9	46.1	44.0	
		8.0	19.2	26.4	32.6	37.5	40.6	45.0	45.8	43.4	40.5
		11.0	19.8	27.5	34.3	39.9	40.0	44.9	46.1	44.3	41.5
	Full Load	6.0		33.3	40.6	46.1		60.2	60.2	56.4	
		9.0	26.0	34.7	42.8	49.1	56.0	60.2	60.8	57.4	52.9
		12.0	26.5	35.7	44.2	50.9	56.1	60.4	61.1	57.6	53.2
064	Part Load	6.0		31.0	39.2	46.1		56.3	55.4	52.1	
		10.0	21.6	31.4	40.9	49.7	52.4	56.2	55.5	52.4	49.4
		14.0	22.6	32.6	41.7	49.8	52.2	56.2	55.6	52.6	49.7
	Full Load	8.0		40.8	52.7	64.7		73.7	75.7	70.3	
		12.0	31.9	43.8	55.1	65.8	66.8	74.1	76.1	70.5	66.2
		16.0	32.2	44.7	56.8	68.6	67.2	74.5	76.5	70.9	66.3
072	Part Load	10.0		36.4	46.5	54.7		63.4	63.0	58.9	
		13.0	25.2	36.7	48.5	59.1	57.7	63.2	63.0	59.2	55.1
		16.0	26.7	38.2	49.4	59.1	57.3	63.2	63.3	59.5	55.4
	Full Load	12.0		48.3	62.7	69.0		81.8	83.0	77.8	
		15.0	37.2	51.6	65.4	70.9	73.6	82.1	83.3	78.0	71.9
		18.0	37.6	52.7	67.5	73.5	74.1	82.6	83.8	78.4	72.2

1/14/11



## Troubleshooting

---

### Aurora Control System

**NOTE:** Refer to the Aurora Base Control Application and Troubleshooting Guide and the Instruction Guide: Aurora Interface and Diagnostics (AID) Tool for additional information.

To check the unit control board for proper operation:

1. Disconnect thermostat wires at the control board.
2. Jumper the desired test input (Y1, Y2, W, O or G) to the R terminal to simulate a thermostat signal.
3. If control functions properly:
  - Check for thermostat and field control wiring (use the diagnostic inputs mode).
4. If control responds improperly:
  - Ensure that component being controlled is functioning (compressor, blower, reversing valve, etc.).
  - Ensure that wiring from control to the component is correct.
  - Refer to the Aurora Base Control Application and Troubleshooting Guide and the Instruction Guide: Aurora Interface and Diagnostics (AID) Tool for additional information.


### Refrigerant Systems

To maintain sealed circuit integrity, do not install service gauges unless unit operation appears abnormal. Compare the change in temperature on the air side as well as the water side to the Unit Operating Parameters tables. If the unit's performance is not within the ranges listed, and the airflow and water flow are known to be correct, gauges should then be installed and superheat and subcooling numbers calculated. If superheat and subcooling are outside recommended ranges, an adjustment to the refrigerant charge may be necessary.

**NOTE:** Refrigerant tests must be made with hot water generator turned "OFF". Verify that air and water flow rates are at proper levels before servicing the refrigerant circuit.

## Startup and Troubleshooting


### Heating Cycle Analysis



$$\text{Heat of Extraction/Rejection} = \text{GPM} \times 500 \text{ (485 for water/antifreeze)} \times \Delta T$$

**Note:** DO NOT hook up pressure gauges unless there appears to be a performance problem.

### Cooling Cycle Analysis



# Troubleshooting cont.

## Single Speed/Dual Capacity Startup/Troubleshooting Form

### 1. Job Information

Model # \_\_\_\_\_

Job Name: \_\_\_\_\_

Loop: Open / Closed

Serial # \_\_\_\_\_

Install Date: \_\_\_\_\_

Hot Water Generator: Y / N

### 2. Flow Rate in gpm

#### SOURCE COAX

##### HEATING

##### COOLING

#### LOAD COAX (Water-to-Water)

##### HEATING

##### COOLING

WATER IN Pressure: a. \_\_\_\_\_ psi a. \_\_\_\_\_ psi a. \_\_\_\_\_ psi a. \_\_\_\_\_ psi  
 WATER OUT Pressure: b. \_\_\_\_\_ psi b. \_\_\_\_\_ psi b. \_\_\_\_\_ psi b. \_\_\_\_\_ psi  
 Pressure Drop: a - b c. \_\_\_\_\_ psi c. \_\_\_\_\_ psi c. \_\_\_\_\_ psi c. \_\_\_\_\_ psi  
 Look up flow rate in table: d. \_\_\_\_\_ gpm d. \_\_\_\_\_ gpm d. \_\_\_\_\_ gpm d. \_\_\_\_\_ gpm

### 3. Temp. Rise/Drop Across Coaxial Heat Exchanger<sup>1</sup>

##### HEATING

##### COOLING

WATER IN Pressure: e. \_\_\_\_\_ °F e. \_\_\_\_\_ °F  
 WATER OUT Pressure: f. \_\_\_\_\_ °F f. \_\_\_\_\_ °F  
 Temperature Difference: g. \_\_\_\_\_ °F g. \_\_\_\_\_ °F

### 4. Temp. Rise/Drop Across Air Coil

#### SOURCE COAX

##### HEATING

##### COOLING

#### LOAD COAX (Water-to-Water)

##### HEATING

##### COOLING

SUPPLY AIR Temperature: h. \_\_\_\_\_ °F h. \_\_\_\_\_ °F h. \_\_\_\_\_ °F h. \_\_\_\_\_ °F  
 RETURN AIR Temperature: i. \_\_\_\_\_ °F i. \_\_\_\_\_ °F i. \_\_\_\_\_ °F i. \_\_\_\_\_ °F  
 Temperature Difference: j. \_\_\_\_\_ °F j. \_\_\_\_\_ °F j. \_\_\_\_\_ °F j. \_\_\_\_\_ °F

### 5. Heat of Rejection (HR)/Heat of Extraction (HE)

Brine Factor<sup>2</sup>: k. \_\_\_\_\_

##### HEATING

##### COOLING

HR/HE = d x g x k l. \_\_\_\_\_ Btu/h l. \_\_\_\_\_ Btu/h

### STEPS 6-9 NEED ONLY BE COMPLETED IF A PROBLEM IS SUSPECTED.

### 6. Watts

#### ENERGY MONITOR

##### HEATING

##### COOLING

Volts: m. \_\_\_\_\_ Volts m. \_\_\_\_\_ Volts  
 Total Amps (Comp. + Blower)<sup>3</sup>: n. \_\_\_\_\_ Amps n. \_\_\_\_\_ Amps  
 Watts = m x n x 0.85: o. \_\_\_\_\_ Watts o. \_\_\_\_\_ Watts

### 7. Capacity

##### HEATING

##### COOLING

Cooling Capacity = l - (o x 3.413): p. \_\_\_\_\_ Btu/h p. \_\_\_\_\_ Btu/h  
 Heating Capacity = l + (o x 3.413): p. \_\_\_\_\_ Btu/h p. \_\_\_\_\_ Btu/h

### 8. Efficiency

##### HEATING

##### COOLING

Cooling EER = p / o: q. \_\_\_\_\_ Btu/h q. \_\_\_\_\_ Btu/h  
 Heating COP = p / (o x 3.413): q. \_\_\_\_\_ Btu/h q. \_\_\_\_\_ Btu/h

### 9. Superheat (S.H.)/Subcooling (S.C.)

##### HEATING

##### COOLING

Suction Pressure: r. \_\_\_\_\_ psi r. \_\_\_\_\_ psi  
 Suction Saturation Temperature: s. \_\_\_\_\_ °F s. \_\_\_\_\_ °F  
 Suction Line Temperature: t. \_\_\_\_\_ °F t. \_\_\_\_\_ °F  
 S.H. = t - s u. \_\_\_\_\_ °F u. \_\_\_\_\_ °F  
 Head Pressure: v. \_\_\_\_\_ psi v. \_\_\_\_\_ psi  
 High Pressure Saturation Temp: w. \_\_\_\_\_ °F w. \_\_\_\_\_ °F  
 Liquid Line Temperature<sup>4</sup>: x. \_\_\_\_\_ °F x. \_\_\_\_\_ °F  
 S.C. = w - x y. \_\_\_\_\_ °F y. \_\_\_\_\_ °F

#### Software Version

ABC: \_\_\_\_\_  
 AXB: \_\_\_\_\_  
 IZ2: \_\_\_\_\_  
 T'STAT: \_\_\_\_\_

**NOTES:** <sup>1</sup> Steps 3-9 should be conducted with the hot water generator disconnected.

<sup>2</sup> Use 500 for pure water, 485 for methanol or Environol™. (This constant is derived by multiplying the weight of one gallon of water (8.34) times the minutes in one hour (60) times the specific heat of the fluid. Water has a specific heat of 1.0.

<sup>3</sup> If there is only one source of power for the compressor and blower, amp draw can be measured at the source wiring connection.

<sup>4</sup> Liquid line is between the coax and the expansion device in the cooling mode; between the air coil and the expansion device in the heating mode.

## Preventive Maintenance

---

### Water Coil Maintenance

1. Keep all air out of the water. An open loop system should be checked to ensure that the well head is not allowing air to infiltrate the water line. Lines should always be airtight.
2. Keep the system under pressure at all times. It is recommended in open loop systems that the water control valve be placed in the discharge line to prevent loss of pressure during off cycles. Closed loop systems must have positive static pressure.

**NOTE:** On open loop systems, if the installation is in an area with a known high mineral content (125 PPM or greater) in the water, it is best to establish with the owner a periodic maintenance schedule so the coil can be checked regularly. Should periodic coil cleaning be necessary, use standard coil cleaning procedures which are compatible with either the cupronickel or copper water lines. Generally, the more water flowing through the unit the less chance for scaling.

### Other Maintenance

#### Filters

Filters must be clean to obtain maximum performance. They should be inspected monthly under normal operating conditions and be replaced when necessary. Units should never be operated without a filter.

#### Condensate Drain

In areas where airborne bacteria produce a slime in the drain pan, it may be necessary to treat chemically to minimize the problem. The condensate drain can pick up lint and dirt, especially with dirty filters. Inspect twice a year to avoid the possibility of overflow.

#### Blower Motors

ECM blower motors are equipped with sealed ball bearings and require no periodic oiling.

#### Air Coil

The air coil must be cleaned to obtain maximum performance. Check once a year under normal operating conditions and, if dirty, brush or vacuum (with a brush attachment) clean. Care must be taken not to damage the aluminum fins while cleaning.



**CAUTION:** Fin edges are sharp.

## Replacement Procedures

---

### Obtaining Parts

When ordering service or replacement parts, refer to the model number and serial number of the unit as stamped on the serial plate attached to the unit. If replacement parts are required, mention the date of installation of the unit and the date of failure, along with an explanation of the malfunctions and a description of the replacement parts required.

### In-Warranty Material Return

Material may not be returned except by permission of authorized warranty personnel. Contact your local distributor for warranty return authorization and assistance.

## Service Parts List

Part Description		Dual Capacity Split Units				
		026	038	049	064	072
Compressor	Compressor	34P640-01	34P641-01	34P642-01	34P643-01	34P644-01
	Run Capacitor	16P002D19	16P002D20	16P002D18	16P002D31	
	Sound Jacket	92P504A16				
	Power Harness	11P781-01				
	Crankcase Heater	19P535-09		19P535-07	19P535-08	
	Solenoid Harness	11P782-02				
Refrigeration Components	Accumulator	36P509-02	36P509-01			
	Coax	62I594-01	62I542B01	62I543B01		
	TXV	33P609-01	33P609-03	33P609-05	33P609-06	
	Reversing Valve	33P506-04	33P503-05	33P526-05		
	Filter Dryer	36P500B01			36P500B02	
Electrical Components	Contactors	13P004A03				
	2 Pole Screw Term. Block	12P500A01				
	ABC Board	17X553-00				
Sensors & Safeties	Freeze Detection Thermistor	12P505B03				
	Low Temperature Sensor	35P505-02				
	High Pressure Switch Kit	SKHPE600				
	Low Pressure Switch Kit	SKLPE40				

Part numbers subject to change

8/14/13

## Revision Guide

---

Pages:	Description:	Date:	By:
All	First Published	03 Sept 2013	DS





Product: **Affinity Outdoor Split Series**  
Type: Geothermal Heat Pumps  
Size: 2-6 Ton Dual Capacity

Document Type: Installation Manual  
Part Number: IM2504SK6  
Release Date: 09/13